

# FOA TOW & TRACK CABLE INSTRUCTIONS

1/6th SCALE FOA WWII TIGER 1

Before you begin, make sure that you have all parts shown in the photo listed below.




## HARDWARE:

- Tow Cables = 2
- Track Cable = 1
- 1/4" Mounts = 13
- 3/16" Mounts = 4
- Copper Rods = 2
- Barrel Cleaning Rods = 6
- #4 Screws (Hardware) = 17

## Tools Needed

- Drill
- 3/32" Drill Bit
- Tape Measure
- 1/32" Socket
- Glue

**WARNING: SMALL PARTS MAY  
POSE CHOKING HAZARD  
TO SMALL CHILDREN**



## Track Cable

---

Step 1:

*Front of Side Plate*

Hole #	Measurement Direction		
	Over	Down	Drill a Hole
1	1"	1 3/16"	3/32"
2	3 3/8"	3/8"	3/32"
3	12 7/8"	1 3/8"	3/32"
4	15 3/8"	1 1/4"	3/32"
5	15 7/8"	5/16"	3/32"

*Back of Side Plate*

Hole #	Measurement Direction		
	Over	Down	Drill a Hole
6	1"	7/8"	3/32"
7	1 1/2"	1 7/8"	3/32"
8	6 1/4"	1/4"	3/32"
9	5 3/4"	1 3/16"	3/32"

## Tow Cables

---

Step 2:

*Front of Top Plate*

Hole #	Measurement Direction		
	Over	Down	Drill a Hole
10	3 7/8"	1 7/8"	3/32"
11	5 1/2"	1"	3/32"
12	10 1/2"	5/8"	3/32"
13	10 1/2"	1 3/4"	3/32"
14	14 1/2"	5/8"	3/32"
15	14 1/2"	1 3/4"	3/32"

*Back of Top Plate*

Hole #	Measurement Direction		
	Over	Down	Drill a Hole
16	4 1/8"	7/8"	3/32"
17	4 3/4"	6"	3/32"

Follow Step 2 to mirror the Tow Cable and Cleaning Rods measurements for other side of Top Plate.

Step 3: Glue 3 barrel cleaning rods together horizontally (see photo above).

Step 4: Cut 2 copper rods 1 1/4" long. Measure each end 1/4" and bend 90°.

Step 5: In holes 12 and 13, insert the ends of one of the Copper Rods. Place the glued Barrel Cleaning Rods under the Copper Rod.

Step 6: In holes 14 and 15, insert the other Copper Rod. Place the glued Barrel Cleaning Rods under the Copper Rod.

If you have any questions, please contact us at [www.fieldofarmortanks.com](http://www.fieldofarmortanks.com).